



## FOOTWELL LIGHT

### ON-VEHICLE INSPECTION

#### 1. INSPECT FOOTWELL LIGHT

- (a) Connect the battery's positive (+) lead to terminal 2 and the negative (-) lead to terminal 1, then check that the light comes on.

**OK:**

**Light comes on.**

If the result is not as specified, replace the light.